



INSTALLATION



UNIVERSAL ISO FLAME GRIPS 6262

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn™ product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA™ All Rights reserved.



FITS THE FOLLOWING HONDAS: SHADOW AERO 1100 '98-'03, SHADOW SABRE 1100 '00-UP, SHADOW SPRIT 1100 '97-'03, SHADOW ACE TOURER 1100 '98-'03, SHADOW ACE 750 DELUXE '98-'03, SHADOW ACE 750 '98-'02, SHADOW AERO 750 '04-UP, SHADOW SPRIT 750 '00-UP, VLX DELUXE '88-UP, VLX '88-UP, MAGNA '94-UP, VTX 1800 (ALL) '02-UP, VTX 1300 (ALL) '03-UP, RUNE '04-UP. MOST MOTORCYCLES WITH 1" BARS.

PART #	INCLUDED
606262	1 Set Metric Flame Grips Including: 2 Maltese End Caps 2 Chrome Rings for ISO Flame Grips 8 4-40 x 3/8" SHCS 18-8 W/Patch 1 1" Diameter Plastic Spacer
306262	2 Adhesive 3 Gram Tube 1 Installation Instructions

THANK YOU FOR CHOOSING KURYAKYN!

CAUTION!

Use extreme care using the glue included in this kit. DO NOT get on skin or in your eyes. See all label warnings on the glue tube.

NOTE

Read and follow all label warnings on the adhesive container. We recommend placing a clean rag over painted or chromed surfaces to protect these finishes from glue drips. Work carefully.

IMPORTANT

This adhesive will set up IMMEDIATELY in the absence of air. If you hesitate even for an instant while sliding these grips into place, the grip will bond permanently in that location.

PROCEDURE RIGHT SIDE

STEP 1 With a razor blade or sharp knife, slice lengthwise through the right grip down to the throttle sleeve. Be very careful not to cut into the sleeve. Remove any decorative end caps etc.

STEP 2 "Peel" the grip completely off of the throttle sleeve. Sand any grip or glue residue off of the sleeve. The sleeve must be absolutely and completely clean. The surface of the throttle sleeve should be slightly roughed so the glue will adhere to it.

STEP 3 Place a clean rag over any painted surface of the bike that glue could drip on. Wipe the interior of the right grip with a clean rag.

IMPORTANT

You have one chance to install this grip correctly. The glue will set up permanently the instant you stop moving it into position!! Be sure you know exactly where you want the grip to end up before you begin pushing it into place.

STEP 4 Apply the glue to the inside of the grip all the way from the top to the bottom of the inside of the grip. You may want to apply a larger amount of glue on the first 1/3 of the inside of the grip since it will have a squeegee effect. You need to use the entire tube of glue for this grip.

STEP 5 In one swift, twisting movement, slide the grip into the desired position on the bar. As soon as you stop moving the grip, that's where it will stay. Apply pressure to the rubber inserts (squeeze them) to make sure the glue has contacted the bar.

PROCEDURE LEFT SIDE

STEP 1 With a razor blade or sharp knife, slice lengthwise through the left grip down to the handlebar the entire length of the grip. Remove any decorative end caps etc.

STEP 2 "Peel" the grip completely off of the handlebar. Sand any grip or glue residue off of the bar. The bar must be absolutely and completely clean. The surface of the handlebar should be slightly roughed.

STEP 3 Measure the length of the exposed handlebar from the switch housing to the end of the bar. Now measure the depth of the grip. Subtract the length of bare handlebar from the depth of the grip. This is the length of the spacer you will make. Cut the spacer from the length of plastic spacer included. A razor blade or sharp knife will work for this. Insert the spacer into the left grip and push it all the way into the grip. Test fit the grip on the bar, and adjust the length of the spacer as needed.

STEP 4 Place a clean rag over any painted surface of the bike that glue could drip on. Wipe the interior of the left grip with a clean rag.

IMPORTANT

You have one chance to install this grip correctly. The glue will set up permanently the instant you stop moving it into position!! Be sure you know exactly where you want the grip to end up before you begin pushing it into place.

STEP 5 Apply the glue to the inside of the grip all the way from the top to the bottom of the inside of the grip. You may want to apply a larger amount of glue on the first 1/3 of the inside of the grip since it will have a squeegee effect. You need to use the entire tube of glue for this grip.

STEP 6 In one swift, twisting movement, slide the grip into the desired position on the bar. As soon as you stop moving the grip, that's where it will stay. Apply pressure to the rubber inserts (squeeze them) to make sure the glue has contacted the bar.

STEP 7 Recheck to make sure the throttle operates freely before starting engine.

Ride On!