



Revision: 1.0 - 03/15/2010

Please read ALL of the instructions BEFORE beginning the installation.

INCLUDED IN THE KIT:

(2) M5 Socket Cap Screws	(4) 5/16-18x3/4 Socket Cap Screws
(4) M5 Set Screws	(2) Longboard Mounts

INSTRUCTIONS:

Unhook spring from underside of stock floorboard.

Remove E-clips from stock pivot pins and remove pins. Retain pin, spring, and E-clip as they will be reused.

Install new floorboard mounts to frame where stock boards were removed using hardware removed in previous step, and placing end of spring in hole on inside of mount. See Photo #1 on reverse side.

Attach new Longboards onto mounts in desired position using supplied M8 cap-head screws. NOTE: not all positions may be usable in all applications.

After floorboard mount screws are tightened, tighten set screw on each end of mount to hold M8 floorboard mount screws in place.

The M5 cap screw in bottom of mount can be used to adjust tilt angle of the floorboard. Adjust to comfort level desired.

Adjust heel shifter so it does not touch floorboard during downshifts. NOTE: heel shifters are removable on most models.

Adjust brake pedal for comfort and safety.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2010 Barons Custom Accessories