



Revision: 1.5 - 02/22/2010

Please read ALL of the instructions BEFORE beginning the installation.

INSTRUCTIONS:

- 1. Remove fender from bike. Remove all lighting hardware.**
- 2. Locate Frenched License box inside fender in your preferred location. *We suggest centering it over the existing holes for the stock license and turn signal wiring.***
- 3. Center and align the box and scribe a line that traces the frame cutout.**
- 4. Cut along the scribed line completely and remove the metal.**
- 5. Sand and/or file rough window to remove all metal burrs.**
- 6. Place the License Box inside the fender, aligning its window with the one you just cut. Now bond the box in place. We recommend you use 3M DP420 or equivalent panel adhesive.**
- 7. Body prep and paint fender as desired.**
- 8. Install your license plate and attach backing plate with the supplied well nuts and screws.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2010 Barons Custom Accessories